




## Components

### Digital Door Lock DH2000





Please read these instructions carefully before you use the product. Functions and design of this product are subject to change without prior notice due to product improvement.

### Front Handle




### Back Handle



### Component List

No	Item	Quantity
1	Front handle	1
2	Back handle	1
3	Accessories	1
4	User manual	1
5	Drilling template	1
6	Tubular latch	1
7	Mechanical key	2



7. Insert the wire from the front handle through the hole into the back handle.

8. Connect the front handle wire into the corresponding socket on the back handle.

9. First, fasten the back handle and front handle with one screw (as shown).

10. Then press the back handle and fasten it with the second screw.

11. Put 4 pcs. of 1.5V AAA alkaline battery into the battery pocket and close the battery cover.

12. Install the strike plate and strike box at the door frame and fasten them with 2 pcs. of self-tapping screws.

## Installation steps

1. Drill a hole into the door with the supplied drilling template.

2. Insert the tubular latch into the door and use 2 pcs. of the self-tapping screw to fix it.

Note that the slant faces the direction of closing the door.

3. Install 2 pcs. of the threaded sleeve at the front handle.

4. Thread the front handle wire through the square spindle hole and fix it.

5. Open the battery cover plate from the tail of the back handle (as shown).

6. Thread the front handle wire and square spindle through the tubular latch.

## Instructions

### Emergency Power Supply

Front handle

Micro USB emergency power port

If the battery is low power or empty, please connect the portable power bank to the USB Emergency power supply port. Instantly you can open the door and replace all batteries immediately.

### Restore Default Settings

Back handle

Function button

Reset button

This procedure will delete all user fingerprints associated with the lock. Use a paper clip to long-press the reset button while the power is on. After hearing the voice prompt, please continue to press the button until restoring the factory settings.

### Mechanical Key Operation

Turn the key 90° and press the handle to open the door.

### Adjust Backset Of Tubular Latch

Backset 60 mm

Backset 70 mm

Follower

If the Backset of your door is 60 mm, no adjustment is required. If the backset is 70 mm, you need to adjust the tubular latch by pushing the follower to a backset of 70 mm.

### Button Function

Function button:  
Passage mode, registered administrator/user fingerprint and mute mode

Reset button:  
Restore default settings, delete the registered administrator/user fingerprint and Bluetooth pairing.

### Back handle

Function button

Reset button

