



Installation Instruction Soft close Dish Basket

495.35.093
495.35.094

A X1 **B** X1 **C** X1 **D** X1 Set **E** X6 **F** X2
G X1 Set **H** X1 Set **I** X2 **J** X4 **K** X6 **L** X6 **M** X8

i **1**

W	W1
600	564-568
800	764-768



2

3

4

**i**

„mm“




W	W1
600	564-568
800	764-768

5


„mm“

6


„mm“



W	598	798
W2	527	727

**7**

„mm“

**8****9**

„mm“

